

Acoustic performance with mineral tiles



Contens 3

Acoustics	Humancare Plus	
Room acoustics 4	Humancare Pro	
Nooni acoustics	Janus   Constellation	24
Acquetic performance with mineral tiles	Janus   Cosmos/N	25
Acoustic performance with mineral tiles 5	NEW Sandila/N	25
Communication and concentration in balance 5	NEW Sandila NRC	25
Reverberation time (T)	Ocean	25
Every room is different	OWAlux®	26
Sound absorption	OWAplan <sup>70</sup>	26
Sound absorption coefficient	OWAplan <sup>90</sup>	26
Equivalent sound absorption area "A" 6	Pix	26
Reverberation time and sound absorption 6	RAW concrete	27
Sound reduction $\Delta L$ through sound absorption 6	RAW grey	27
Single figure sound absorption 6	Sanitas® 02   Plain	27
Sound absorption coefficient $\alpha_s$	Sinfonia and Sinfonia   Humancare	27
Practical sound absorption coefficient $\alpha_p \cdots 7$	Sinfonia Balance	28
Weighted sound absorption coefficient $\alpha_{\rm w}$	Sinfonia black or grey	28
Noise Reduction Coefficient NRC	Sinfonia c and Sinfonia c   Humancare	
Sound Absorption Average SAA	Sinfonia FR	28
Speech Range Absorption SRA	Sinfonia Privacy	29
	Sinfonia Reflecta	29
Room acoustics 8	Sinfonia Silencia and Sinfonia Silencia   Humancare	29
	Sinfonia sports	29
Room acoustic planning according DIN 18041 8 Rooms in group A	Trapeze	30
Rooms in group B		
100m3 in group B	Sound absorption figures   Wall absorber	31
Building acoustics 17	Corpus	31
	Creaprint, Curve and Selecta	
Room to room airborne sound reduction	FreeStyle	
Sound attenuation	S 60	
Airborne sound reduction	0 00	01
Noise from the ceiling void	Sound absorption area   Baffles	32
Attention to installations		
Sketch of the test assembly for sound absorption	FreeStyle	32
measurements	Cound absorption area I Canonica	
Cound absorption figures aversion	Sound absorption area   Canopies	33
Sound absorption figures overview 20	Cloud	33
	Corpus S	33
Sound absorption figures22	Corpus M	33
Bamboo   Constellation	Corpus L	33
Bamboo   Regular perforated	Corpus XL	34
Bolero	Corpus XXL	34
Brillianto A (14 mm)	Curve 1 and Curve 2	34
Brillianto A (20 mm)	Selecta one, plus, grande and grande XL	34
Constellation. 23	Selecta loop	35
Cosmos/N	Selecta Metall one, plus and grande	35
Flexo. 23	Square	35
Humancare Lab		

The continuous increase of noise levels in everyday life give sound protection an ever more important role, particularly in modern high rise developments. We are all entitled to live and work in a comfortable acoustic environment. To achieve this all project partners should be involved in the planning.

OWAcoustic ceiling systems can be used to provide a number of acoustic benefits. The following simple chart shows the dual acoustic functions that can be provided by the installation of the correct OWAcoustic ceiling system.



- to optimize reverberation times
- to decrease the noise level ΔL [dB] in production and maintenance facilities
- to increase the airborne sound insulation  $R_w$  [dB] of solid and timber beam soffits as well as simple roof constructions
- to improve the room to room airborne sound reduction  $D_{\text{n,f,w}}$  [dB]/ CAC [dB] between adjacent areas
- to reduce unwanted noise from the ceiling cavity

The following describes the areas of use for OWAcoustic ceiling systems greater detail.

#### Room acoustics

As a division of acoustics, room acoustics are concerned with the internal characteristics of specific areas. Wherever possible the proposed use of the room should be taken into account at the design stage. If the primary use requires good speech intelligibility, the interior design of the room will be different from that of a room whose primary use is music practice or recital. Where a room is to be used for both purposes a degree of compromise is required.

#### The most important factors which influence the acoustic quality of an area:


- 1. Location of the room within the building
- 2. Sound insulation of the adjacent construction
- 3. Noise generation from service facilities
- 4. Shape and size of the room (primary structure)
- 5. Sound absorption characteristics of all surfaces (secondary structure)
- 6. Furnishing objects in the room (secondary structure)
- 7. Dimensioning and spatial distribution of sound absorbing and reflecting surfaces

Having good room acoustics is a complex task, which is becoming a more and more important compared to other building physics issues. Builders, planners and architects are increasingly interested in the subjected specifically in view of DIN 18041 "Acoustic quality in rooms". In this context, sound absorbing acoustic ceilings are playing a very important role due to their surface size. The ceiling is often the most suitable surface to provide effective sound absorption and reflection. By dimensioning the acoustic ceiling early in a manner that reflects its intended use, the reverberation time can be fine-tuned to meet the needs of the customer.

#### Communication and concentration in balance

Employees are an important company asset and the provision of a comfortable, attractive working environment is very important. Acoustically, areas should allow effective communication between co-workers without being intrusive, a balance between communication and concentration. OWAcoustic ceilings can be used as a key element in the design of an efficient workspace providing acoustic control, a range of versatile systems and the ability to integrate services within the ceiling plane. As an introduction we explain below some of the acoustic terms you may encounter.

#### Reverberation time (T)



Reverberation time is the oldest and best known performance criteria in the field of acoustics. It is measured in seconds and is defined as the time taken for a generated sound to decay by 60 dB once the sound source has been stopped.

## Every room is different

The optimum reverberation time for a room is dependant on its intended use be it office, conference room, classroom, cafeteria or library. Lists of recommended reverberation times for a variety of applications are available from a number of recognised sources such as DIN 18041. Measurement of the rooms RT and any subsequent calculations will be dependant on a number of the room's physical attributes. These include the dimensions and shape of the room, the construction and materials used for the interior surfaces and the type and position of any other materials used in the room.


## Sound absorption

The sound absorption shows how much the sound is reduced on the boundary surfaces of the room. It is the most important parameter in the acoustic design of rooms. If the sound-absorbing and sound-reflecting properties of interior surfaces have been dimensioned correctly, the resulting room acoustics will meet the needs of spoken word or music. Usually, acoustic products in the ceiling area are more than adequate. In special cases, we recommend combined measures for both the ceilings and walls. It is imperative to ensure that reflecting and absorbing surfaces are correctly positioned.

#### Sound absorption coefficient

The sound absorption coefficient of a material describes its ability to absorb sound and is measured over a number of specific frequencies. The result is expressed as a number between 0 and 1 where 0 is total reflection and 1 is total absorption. If the coefficient is multiplied by 100, it provides the percentage of incident sound that is absorbed.

= 0.75 means: =  $0.75 \times 100\% = 75\%$  sound absorption (the remaining 25% is sound reflection)



#### Equivalent sound absorption area "A"

The equivalent sound absorption area (A) is the amount of a material with a sound absorption of  $\alpha = 1$  (100 %) that would be needed to provide the required reverberation time. The equation  $A = \alpha \times S$  can be used to calculate the equivalent surface area of a material with a sound absorption (" $\alpha$ ") of less than 1.

#### Reverberation time and sound absorption

In many project designs, the reverberation time is calculated using a formula that portrays the relationship between the reverberation time T, room volume V and equivalent sound absorption area A.

$$T = 0.163 \text{ x} \qquad \qquad T = 0.163 \text{ x} \qquad \frac{\text{Room volume}}{\text{Equivalent sound absorption area}}$$
 
$$A = \alpha_{\text{Floor}} \text{ x area}_{\text{Floor}} + \alpha_{\text{Wall}} \text{ x area}_{\text{Wall}} + \alpha_{\text{Ceiling}} \text{ x area}_{\text{Ceiling}} + \text{ other absorbing surfaces}$$
 
$$A... \text{ is the total sound absorption of the surfaces within the room}$$

#### Sound reduction $\Delta L$ through sound absorption

When sound absorbing materials are placed in a room the sound level decreases and results in a more diffuse sound field

$$\Delta L = 10 \text{ x lg } \frac{A_2}{A_1} = 10 \text{ x lg } \frac{T_1}{T_2} \text{ in[dB]}$$

In this equation  $A_1$  represents the empty room and  $A_2$  the room after the introduction of the absorbing materials. Note: the full effect of the absorbing materials will not be realised if the subject or measuring equipment is placed in the immediate.

## Single figure sound absorption

To enable simple comparison of products the sound absorption performance is also shown as a single figure. However the single figures results do not reflect the full performance and are generally not adequate for an accurate acoustic calculation.

#### Sound absorption coefficient $\alpha_s$

Materials are tested for their ability to absorb sound by being placed in a reverberation chamber and tested in accordance with EN ISO 354. The test is carried out over 18 separate frequencies from 100 Hz to 5000 Hz and the results reported individually as a sound absorption coefficient ( $\alpha_s$ ) between 0.00 (total reflection) and 1.00 (total absorption). Using these results a number of single figures can be produced:

#### Practical sound absorption coefficient $\alpha_{\rm p}$

To ascertain the single value specification  $\alpha_w$ , the specified frequency-dependent sound absorption coefficients  $\alpha_s$  must be converted into so-called practical sound absorption coefficients  $\alpha_P$  for every octave band. To do this, the sound absorption values of three one-third octaves (e.g. for 100 Hz, 125 Hz and 160 Hz) are added, calculated mathematically and rounded up to the nearest 0.05.

$$\alpha_{p,125 \text{ Hz}} = \frac{\alpha_{s,100 \text{ Hz}} + \alpha_{s,125 \text{ Hz}} + \alpha_{s,160 \text{ Hz}}}{3}$$

Using this method, the 18 frequency-dependent sound absorption coefficients  $\alpha_S$  are converted to 6 practical sound absorption coefficients  $\alpha_P$ .

#### Weighted sound absorption coefficient $\alpha_{w}$

The standard EN ISO 11654 is used to determine the weighted sound absorption coefficient  $\alpha_w$ . The single value  $\alpha_w$  is determined according to a precisely defined evaluation procedure. The reference curve specified in the norm is shifted against the curve from the ascertained  $\alpha_P$  values in 0.05 increments until the sum of the values below the reference curve is less than or equal to 0.10. The weighted sound absorption coefficient  $\alpha_w$  corresponds to the value of the shifted reference curve at 500 Hz.

In addition, attachment B of EN ISO 11654 contains information about the classification of the single number specification  $\alpha_w$  in the following absorption classes:

Absorption class	$\alpha_{w}$ -value [-]
А	0.90; 0.95; 1.00
В	0.80; 0.85
С	0.60; 0.65; 0.70; 0.75
D	0.30; 0.35; 0.40; 0.45; 0.50; 0.55
Е	0.15; 0.20; 0.25
Not classified	0.00; 0.05; 0.10

#### Noise Reduction Coefficient NRC

The American Standard ASTM 423 provides similar test criteria to EN ISO 354 and also provides a method for calculating a single figure result called a "Noise Reduction Coefficient" or "NRC". This is calculated using the following equation.

$$NRC = \frac{\alpha_{250 \text{ Hz}} + \alpha_{500 \text{ Hz}} + \alpha_{1000 \text{ Hz}} + \alpha_{2000 \text{ Hz}}}{4}$$

The result is reported in increments of 0.05

Example: 
$$NRC = {0.39 + 0.58 + 0.73 + 0.61 \over 4} = 0.58 \longrightarrow NRC = 0.60$$

## Sound Absorption Average SAA

The ASTM standard C 423 also specifies the single-value SAA sound absorption average. This single-value parameter is calculated as follows:

$$SAA = \frac{1}{12} \sum_{200 \text{ Hz}}^{i = 2500 \text{ Hz}} \alpha_i$$

# Speech Range Absorption SRA

The single-value parameter for average sound absorption in the speech frequency range can be determined as follows:


SRA = 
$$\frac{\alpha_{500 \text{ Hz}} + \alpha_{1000 \text{ Hz}} + \alpha_{2000 \text{ Hz}} + \alpha_{4000 \text{ Hz}}}{4}$$

8 Room acoustics

#### Room acoustic planning according DIN 18041


The revised DIN 18041 standard "Acoustic quality in rooms - requirements, recommendations and instructions for planning" has been available for room acoustic planning purposes since March 2016. The following quick overview is designed to help you gain a better understanding of the structure of DIN 18041, the internationally wide recognised standard for acoustics. Please note that your local standards may vary.

#### **Overview**



The relevant areas are subsequently structured as follows:

#### **Overview**



E.g. classrooms in schools, group rooms in day-care facilities conference rooms, court and council halls, seminar rooms, auditoriums, meeting rooms, rooms in senior day-care centres, sports halls and indoor swimming facilities

E.g. frequented spaces with amenity value, dining rooms, canteens, corridors and changing rooms in schools and day-care centres, exhibition rooms, entrance halls, halls, offices

In what way do the two area groups differ?

Areas in group A: definite requirements are fixed.

Areas in group B: only estimates "in respect of" are given.

Room acoustics

# Rooms in group A


The spaces included in group A are further broken down depending on so-called types of use. The table below provides further information on the types of use A1 to A5. In addition to a description of the type of use, it also contains information on how to classify subjective perceptions. A few examples of spaces are also provided for type of use. Under DIN 18041, comparable spaces should be classified analogously.

Type of use	Short name and description of the type of use	Subjective perception	Examples
A1	Short name: "Music" mainly musical performances	Good acoustic quality for unamplified music.  Speech delivery only possible with certain limitations to speech intelligibility.	Music classrooms with active music and singing
A2	Short name: "Speech/lecture"  Speech is a priority, usually delivered from a (frontal) position.  Simultaneous communications between several persons positioned in different parts of the room are rare.	Speech performances of individual speakers are highly intelligible.  Musical performances tend to be perceived as too transparent and clear, but advantageous for rehearsals.	Court and council chambers community halls lecture halls assembly halls auditoriums
A3	Short name: "Speech/lecture inclusive"  Spaces as defined under A2, for persons who are particularly dependent on good speech intelligibility.  Required for inclusive use*	Speech performances of individual speakers are highly intelligible, including for persons with hearing impairments or when speaking in a foreign language.	Court and council chambers community halls lecture halls assembly halls auditoriums
	Short name: "Teaching/communication"  Communications-intensive uses with multiple simultaneous speakers distributed across the room.	Speech communications (in part simultaneous) with multiple speakers are possible.	Classrooms multi-purpose rooms conference rooms meeting rooms conference facilities seminar rooms group spaces in day-care centres, nursing homes and retirement homes
A4	Short name: "Teaching/communication inclusive"  Communications-intensive uses with multiple simultaneous speakers distributed across the room as defined under A3, for persons who are particularly dependent on good speech intelligibility.  This type of use is not suitable for music uses or rooms larger than 500 m².  Required for inclusive use*	Speech communications (in part simultaneous) with several speakers are possible, including for persons with hearing impairments or when speaking in a foreign language.	Classrooms multi-purpose rooms conference rooms meeting rooms conference facilities seminar rooms group spaces in day-care centres, nursing homes and retirement homes video conference rooms
A5	Short name: "Sport"  In sports and indoor swimming facilities several groups communicate (including simultaneously) different content.	Speech communication over short distances is generally possible.	Sports and indoor swimming facilities used nearly exclusively as sports venues

<sup>\*</sup> Under the German Disability Discrimination Act, similar state legislation and the UN Convention on the Rights of Persons with Disabilities, publicly accessible new buildings must be designed and constructed to be inclusive and accessible to people with disabilities, provided this does not lead to a disproportionate increase in costs. For details, please refer to the relevant state legislation.

#### Determining the target reverberation time requirement

With the help of room volume V [ $m^3$ ], the room acoustic requirements in the form of the target reverberation time  $T_{target}$  [s] can be calculated for each group A room type. This target reverberation time must be backed up by a suitable room acoustic design. The next chart shows the relationship between the target reverberation time  $T_{target}$  [s] and room volume V [ $m^3$ ] for the types of use A1 to A5.




By using the relevant formula, the concrete target reverberation time requirement  $T_{target}$  [s] can be calculated for each type of use. The formula used in the calculation of room volume V [m³] relates to the end result where the room features a suspended ceiling. If no suspended ceiling is brought to bear (e.g. in the case of an acoustic design with fins/baffles or ceiling canopies), the ceiling height h [m] without a suspended ceiling is used to calculate room volume V [m³].

Type of use		Volume range	Target reverberation time formula	
A1	Music	30 m³ ≤ V < 1000 m³	$T_{target,A1} = [0.45 \times log(V) + 0.07] s$	
A2	Speech/lecture	50 m³ ≤ V < 5000 m³	$T_{\text{target,A2}} = [0.37 \times \log(V) - 0.14] \text{ s}$	
A3	Teaching/communication (up to 1000 m³)	003 < 1/ < 50003	$T_{target,A3} = [0.32 \times log(V) - 0.17] s$	
	Speech/lecture inclusive (up to 5000 m³)	30 m³ ≤ V < 5000 m³		
A4	Teaching/communication inclusive	$30 \text{ m}^3 \le \text{V} < 500 \text{ m}^3$	$T_{target,A4} = [0.26 \times log(V) - 0.14] s$	
٨٥	Chart	200 m³ ≤ V < 10000 m³	$T_{target,A5} = [0.75 \times log(V) - 1.00] s$	
A5	Sport	V ≥ 10000 m <sup>3</sup>	T <sub>target,A5</sub> = 2.0 s	

The target reverberation time requirements relate to the occupied state (occupancy rate of 80 %). In planning and conformity testing, the conversion between the unoccupied and occupied state must be carried out in accordance with the requirements set out in annex A of DIN 18041.


Room acoustics

In practice, it is possible to deviate from this target reverberation time requirement to some extent.



This chart shows the tolerance range for frequency-dependent reverberation time between 125 Hz and 4000 Hz, which needs to be observed in relation to the reverberation time  $T_{target}$  [s]. This tolerance range applies to the types of use A1 to A4. Only indicative values are provided for frequencies outside the tolerance range from 125 Hz to 4000 Hz.

Tolerance range for the type of use A1 to A4



A tolerance range between 250 Hz and 2000 Hz +/- 20 % is required to be met for target reverberation time  $T_{\text{target, A5}}$  [s] for the type of use A5.

Tolerance range for the type of use A5


#### **Example:**

Here, we calculate the target reverberation  $T_{target}$  [s] for a classroom with 180 m<sup>3</sup> room volume. Classrooms without inclusive/barrier-free requirements fall into the "Teaching/communication" type of use and the relevant formula for "Teaching/communication" to be used is therefore:

$$\begin{split} T_{target,A3} &= [0.32 \text{ x log(V)} - 0.17] \text{ s} \\ T_{target,A3} &= [0.32 \text{ x log(180 m}^3) - 0.17] \text{ s} \\ T_{target,A3} &= 0.55 \text{ s} \end{split}$$

In practice, it is possible to deviate from the target reverberation time to some extent. In the frequency range from 250 Hz to 2000 Hz, the deviation can range between  $\pm$  20%.

Calculation of the tolerance range for a classroom with  $V = 180 \text{ m}^3$ :



Tolerance range for the reverberation time for teaching/communication when  $V=180\ m^3$ 

### Rooms in group B

DIN 18041 only specifies recommendations for rooms in group B that are intended to improve acoustic quality reflecting the use of the space over short distances. Through appropriate sound absorption measures, the average basic noise level is lowered and the reverberation limited.

The recommendations for rooms in group B are specified using the A/V ratio, where A  $[m^2]$  is the equivalent sound absorption area and V  $[m^3]$  is the room volume. They are valid for the frequency range 250 Hz to 2000 Hz.

Depending on the type of use, rooms in group B are further broken down into categories B1 to B5. In the table below, the respective types of use are described and illustrated with examples. Under DIN 18041, comparable spaces should be classified analogously. In rooms with multiple uses or types of use, e.g. waiting area in a hospital with a hall in use 24/7, the higher A/V ratio recommendation should be used.

Type of use	Description	Examples
B1	Spaces without amenity value	Entrance halls, corridors, stairwells i.a. as pure traffic areas (except traffic areas in schools, day care centres, hospitals and nursing homes)
B2	Spaces intended for short-term use	Entrance halls, corridors, stairwells i.a. traffic areas with amenity value (lobby with waiting areas, etc.), exhibition rooms, halls, changing rooms in sports facilities
B3	Spaces intended for long-term use	Exhibition rooms with interactive features or increased noise levels (multimedia, sound/video art, etc.), traffic areas in schools and day care centres (kindergarten, nursery, crèche etc.), traffic areas with amenity value in hospitals and care facilities (e.g. open waiting zones), patient waiting rooms, rest rooms, bedrooms, quiet zones, operating theatres, treatment rooms, examination rooms, consulting rooms, dining rooms, canteens, laboratories, libraries, showrooms
B4	Rooms requiring noise control and acoustic comfort	24/7 receptions/counter areas, 24/7 laboratories, lending areas of libraries, food service areas in canteens, residents' rooms in nursing homes, local council offices, office facilities*°
B5	Rooms with special needs for noise control and acoustic comfort	Dining rooms and canteens in schools, day-care centres (kindergarten, nursery, crèche etc.), hospitals and nursing homes, workspaces with particularly high noise levels (e.g. workshops, work facilities, large kitchens, sculleries), call centres*, control rooms, security centres, intensive care units, infirmaries, public areas in childcare centres, play corridors and locker rooms in schools and day-care centres (kindergarten, nursery, crèche etc.)

<sup>\*</sup> Recommendations for offices and call centres are covered in detail in the VDI 2569 standard.

<sup>°</sup> Individual offices fall into the type of use B3.

Room acoustics

#### Indicative values for the A/V ratio

To determine the minimum required A/V ratio in the frequency range 250 Hz to 2000 Hz for the respective type of use, the following table must be used. All that is needed for this purpose is the ceiling height h [m].

Type of use	Room heights h ≤ 2.5 m [m²/m³]	Room heights h > 2.5 m [m²/m³]
B1	No requirement	No requirement
B2	$A/V \ge 0.15 (\approx T < 1.09 s)$	$\frac{A}{V} \ge \frac{1}{4.80 + 4.69 \times \log(\frac{h}{1 \text{ m}})}$
В3	A/V ≥ 0.20 ( ≈ T < 0.82 s)	$\frac{A}{V} \ge \frac{1}{3.13 + 4.69 \times \log(\frac{h}{1 \text{ m}})}$
В4	$A/V \ge 0.25 (\approx T < 0.65 s)$	$\frac{A}{V} \ge \frac{1}{2.13 + 4.69 \times \log(\frac{h}{1 \text{ m}})}$
B5	A/V ≥ 0.30 ( ≈ T < 0.54 s)	$\frac{A}{V} \ge \frac{1}{1.47 + 4.69 \times \log(\frac{h}{1 \text{ m}})}$

Where A the equivalent sound absorption area of a room in square metres

V is the volume in cubic metres

h is the ceiling height in metres

The following example illustrates how to use the minimum required A/V ratio to arrive at concrete acoustic product parameters.

#### **Example**

Room example: Canteen with food service area in a production facility/company

Type of use: B4

Description: Rooms requiring noise control and acoustic comfort

Room data: Floor area  $A = 20 \text{ m x } 7.5 \text{ m} = 150 \text{ m}^2$ 

ceiling height to the suspended acoustic ceiling h = 3.50 m

room volume  $V = 525 \text{ m}^3$ 

Starting position: A room which needs to be optimised in terms of acoustics, has in its initial condition a certain equivalent

sound absorption area  $A_{initial}$  [m<sup>2</sup>].  $A_{initial}$  is derived from the respective surface units and the associated sound absorption properties of the room interior surfaces (walls, ceilings, doors, windows) as well as the

interior design.

In our experience with previous measurements, rooms where no specific sound absorption measures have been implemented can be assumed to have an A/V ratio

 $\left(\frac{A}{V}\right)_{\text{initial}} = 0.03 \text{ to } 0.12 \quad \frac{1}{m} \text{ depending on interior furnishings.}$ 

Assumption: A canteen has  $\left(\frac{A}{V}\right)_{initial} = 0.06 \frac{1}{m}$ 

Next, it is checked what is the lowest A/V ratio necessary to comply with the recommendations laid down in DIN 18041 in this example:

Calculation of minimum req.  $\frac{A}{V}$ : given the ceiling height h> 2.50 m and type of use B4

the formula to be used is 
$$\frac{A}{V} \ge \frac{1}{2.13 + 4.69 \text{ x log}(\frac{h}{1 \text{ m}})}$$
 with h = 3.50 m!

Result 
$$\rightarrow \frac{A}{V} \ge 0.21 \frac{1}{m}$$

As the canteen, which has not been acoustically treated, has an initial A/V ratio of 0.06  $\frac{1}{m}$ ,

this can be deducted from the minimum required A/V ratio of 0.21  $\frac{1}{m}$ :

additionally req. 
$$\left(\frac{A}{V}\right) = 0.21 \frac{1}{m} - 0.06 \frac{1}{m} = 0.15 \frac{1}{m}$$

The additionally required equivalent sound absorption area A in the cantina is therefore determined as follows:

additionally req. A = V x 0.15 
$$\frac{1}{m}$$
 = 525 m<sup>3</sup> x 0.15  $\frac{1}{m}$  = 79 m<sup>2</sup>

This means that the canteen needs an acoustic product which will provide an equivalent sound absorption area of  $A = 79 \text{ m}^2$ .

There are different solutions, which can provide the canteen with an equivalent sound absorption area of  $A = 79 \text{ m}^2$ .

If a highly absorbent acoustic product with the following parameters would be used,

Frequency [Hz]	250 Hz	500 Hz	1000 Hz	2000 Hz
$\alpha_{P}$ -value	1.00	1.00	1.00	1.00

only 79 m² of the existing ceiling surface would have to be covered by it. Only a few products can deliver these sound absorption properties under laboratory conditions. However, the fact that many everyday spaces often have insufficient sound diffusion (sound scattering) is much more important. These conditions mean that these products' existing absorption capacity can only have a limited or reduced effect.

Instead of relying only on high sound absorption properties of acoustic products, it is important to use efficient and acoustically balanced acoustic designs. In a canteen, for example, a combined acoustic solution using a ceiling and a wall would, in many cases, be much more effective than a one-dimensional acoustic ceiling solution with highly absorbent ceiling panels.

In order to be able to select a concrete product, it is important to know how many square metres of the existing ceiling surface  $(S_{ceiling} = 150m^2)$  will indeed be used for room acoustic purposes.

#### Acceptance

acoustic ceiling **Option 1** 
$$\rightarrow$$
 S<sub>Acoustic ceiling</sub> = 150 m<sup>2</sup> using the whole surface **Option 2**  $\rightarrow$  S<sub>Acoustic ceiling</sub> = 110 m<sup>2</sup> using only part of the surface

Now, the minimum required practical sound absorption coefficient  $\alpha_P$  in the 250 Hz to 2000 Hz frequency range can be calculated as follows:

Room acoustics

Option 1 – using the whole ceiling surface (150 m²)

$$\alpha_P = \frac{req.~A}{S_{Acoustic~ceiling}} = ~\frac{79~m^2}{150~m^2} = 0.53$$

This  $\alpha_P$  value must be adhered to in the 250 Hz to 2000 Hz frequency range.

Recommended product would be e.g. Brillianto (12 mm):

Frequency [Hz]	250 Hz	500 Hz	1000 Hz	2000 Hz
α <sub>P</sub> value	0.60	0.65	0.70	0.90

**Option 2** – using only part of the ceiling surface (110 m²)

$$\alpha_P = \frac{erf.~A}{S_{Acoustic~ceiling}} = ~\frac{79~m^2}{110~m^2} = 0.72$$

This  $\alpha_P$  value must be adhered to in the 250 Hz to 2000 Hz frequency range.

Recommended product would be e.g. Sinfonia (15 mm):

Frequency [Hz]	250 Hz	500 Hz	1000 Hz	2000 Hz
α <sub>P</sub> value	0.75	0.80	0.80	0.90

Building acoustics 17


#### Room to room airborne sound reduction

In many buildings partition walls are not installed to the soffit, but extend only to suspend ceiling level. This makes partitions easier to move and provides a more flexible workspace.

Where this type of construction is used care must be taken to ensure that airborne sound transmission through the common cavity is controlled, especially between sensitive areas.

The sound reduction between two areas is determined by the whole construction. Walls and ceilings are part of this as well as flanking passages through shafts, ducts, cavities and joints. If the ceiling is to work well in the total system it must possess a good value of sound insulation.

#### Diagram:



#### System S 3 (or equivalent) solution comparisons:

No.	OWAcoustic premium design	Additional overlays	Sound attennation $D_{n,f,w}$ [dB] (lab value)
1	15 mm perforated tile	-	31 dB
2	15 mm perforated tile	25 mm rock wool	37 dB
3	15 mm fleece covered	-	28 dB
4	20 mm fleece covered Sinfonia Privacy	-	40 dB
5	15 mm perforated tile	Second 15 mm tile	40 dB
6	33 mm perforated tile Janus	=	49 dB
7	15 mm perforated tile	25 mm rock wool and 15 mm tile	49 dB

#### Sound attenuation

The sound attenuation performance of an OWAcoustic ceilings can be enhanced using a number of additional measures:

- additional insulation layer in the PE film bag
- additional insulation layer with aluminium lamination
- additional insulation layer with a non-perforated sheet metal cover
- installation of a vertical cavity barrier above the walls/partitions
- tile thickness, e.g. 15 mm tiles against 33 mm Janus tiles
- suspension height  $h = 700 \text{ mm} (D_{n,f,w} = 31 \text{ dB})$

$$h = 400 \text{ mm } (D_{n,f,w} = 33 \text{ dB})$$

additional back painting

#### Airborne sound reduction

OWAcoustic ceilings can also improve the airborne sound reduction of a structural floor and with the correct selection of system, surface design and additional overlay can significantly reduce noise generated in the ceiling cavity. This is about preventing as much sound energy escaping from one area and intruding into another.

Sound will always try to escape however; its spread will be restricted by the acoustic effectiveness of the perimeter (floors, walls, ceilings, doors and windows, etc).


If the airborne sound insulation of the soffit (steel reinforced concrete, timber beams etc.) needs to be improved, it can be achieved with an OWAcoustic suspended ceiling which will function as a resolution barrier below the soffit.

Laboratory tests were carried out at the Fraunhofer institute for Building Physics (IBP) in Stuttgart to establish the airborne sound improvement measurements  $\Delta R_w$  [dB] between adjacent areas for different OWAcoustic ceilings. The tests were carried out using standard 140 mm thick steel reinforced concrete soffit:

Tested variations		Sound insulation values R <sub>w</sub> [dB]	Impact noise values L <sub>n,w</sub> [dB]
	140 mm thick standard steel reinforced concrete soffit without a suspended ceiling. In the laboratory, the sound transfer takes place only from above to below as the sound passage over the partition walls are blocked (by using gypsum - resolution barriers on the walls)	56 dB	78 dB
	S 3 exposed grid system 600 x 600 mm module 15 mm OWAcoustic premium tiles design Constellation depth H = 300 mm no mineral wool overlay	65 dB	62 dB
	S 3 exposed grid system in 600 x 600 mm module 33 mm OWAcoustic janus-tiles design Constellation depth H = 300 mm no mineral wool overlay	65 dB	– dB
	S 3 exposed grid system 600 x 600mm module 15 mm OWAcoustic premium tiles design Constellation depth H = 300 mm 80 mm ISOVER TP1 acoustic mineral wool overlay	68 dB	61 dB
	S 3 exposed grid system in 600 x 600 mm module 33 mm OWAcoustic janus-tiles design Constellation depth H = 300 mm 80 mm ISOVER TP1 acoustic mineral wool overlay	70 dB	– dB

## Noise from the ceiling void

Service elements such as ventilation ducts, water pipes and air conditioning can all produce noise levels that can disturb and annoy people in the workspace below. Laboratory tests have shown that the use of an OWAcoustic ceiling can help reduce the noise by between 14 – 33 dB.



Tile	Thickness	$R_w$
OWAcoustic premium fleece covered tile (Sinfonia, Bolero, Brillianto A)	15 and 20 mm	14 dB
OWAcoustic premium tile (e.g. Constellation, Cosmos/N)	15 mm	17 dB
OWAcoustic premium tile	15 mm OWAcoustic tile + 20 mm mineral wool	21 dB
OWAcoustic Sinfonia Privacy	20 mm	24 dB
OWAcoustic premium Janus	33 mm	25 dB
OWAcoustic premium tiles	15 mm OWAcoustic tile + 20 mm mineral wool + 15 mm OWAcoustic tile	33 dB

#### Attention to installations

The installation of light fittings, light troughs or air conditioning outlets can seriously affect the sound insulation of the suspended ceiling. Care must be taken not to leave any open holes or gaps.

## Sketch of the test assembly for sound absorption measurements




	P	Practical	sound al	osorption	n figure a	$\ell_{\mathrm{p}}$	NRC	$\alpha_{\mathbf{w}}$	Absorber	
Dessin	125	250	500	1000	2000	4000	value	value	class	Page
Bamboo   Constellation	0.40	0.50	0.60	0.70	0.75	0.70	0.65	0.70	С	22
Bamboo   Regular perforated	0.25	0.40	0.55	0.75	0.60	0.40	0.60	0.55	D	22
Bolero	0.50	0.75	0.80	0.80	0.90	0.90	0.85	0.85	В	22
Brillianto A (14 mm)	0.45	0.80	0.85	0.90	0.95	1.00	0.90	0.90	Α	22
Brillianto A (20 mm)	0.50	0.80	0.90	0.90	1.00	1.00	0.95	0.95	Α	23
Constellation	0.30	0.50	0.60	0.75	0.85	0.80	0.70	0.70	С	23
Cosmos/N	0.35	0.55	0.65	0.70	0.65	0.50	0.65	0.65	С	23
Flexo	0.50	0.80	0.85	0.90	1.00	0.95	0.90	0.90	А	23
Humancare Lab	0.40	0.55	0.60	0.75	0.90	0.95	0.70	0.70	С	24
Humancare Plus	0.40	0.70	0.80	0.90	1.00	1.00	0.90	0.90	А	24
Humancare Pro	0.40	0.85	0.95	0.90	1.00	1.00	0.95	0.95	Α	24
Janus   Constellation	0.30	0.45	0.65	0.90	0.90	0.75	0.70	0.70	С	24
Janus   Cosmos/N	0.25	0.40	0.70	0.85	0.65	0.50	0.65	0.65	С	25
NEW Sandila/N	0.50	0.60	0.70	0.75	0.60	0.40	0.65	0.60	D	25
NEW Sandila NRC	0.50	0.60	0.65	0.85	0.75	0.50	0.75	0.65	С	25
Ocean	0.50	0.80	0.90	0.90	1.00	1.00	0.95	0.95	А	25
OWAlux®	0.15	0.15	0.10	0.15	0.15	0.10	0.15	0.15	Е	26
OWAplan <sup>70</sup>	0.40	0.55	0.55	0.70	0.90	1.00	0.70	0.65	С	26
OWAplan <sup>90</sup>	0.50	0.75	0.85	0.90	1.00	1.00	0.90	0.90	А	26
Pix	0.50	0.80	0.85	0.90	1.00	0.95	0.90	0.90	А	26
RAW concrete	0.40	0.50	0.60	0.75	0.85	0.80	0.70	0.70	С	27
RAW grey	0.45	0.75	0.85	0.90	1.00	1.00	0.90	0.90	А	27
Sanitas® 02   Plain	0.15	0.15	0.10	0.15	0.15	0.10	0.15	0.15	E	27
Sinfonia	0.50	0.80	0.85	0.90	1.00	0.95	0.90	0.90	А	27
Sinfonia   Humancare	0.50	0.80	0.85	0.90	1.00	0.95	0.90	0.90	Α	27
Sinfonia Balance	0.45	0.50	0.80	1.00	1.00	1.00	0.80	0.80	В	28
Sinfonia black or grey	0.50	0.65	0.80	0.85	0.95	1.00	0.80	0.85	В	28
Sinfonia c	0.40	0.60	0.65	0.65	0.75	0.75	0.70	0.70	С	28
Sinfonia c   Humancare	0.40	0.60	0.65	0.65	0.75	0.75	0.70	0.70	С	28
Sinfonia FR	0.30	0.35	0.55	0.80	0.90	0.90	0.65	0.60	С	28
Sinfonia Privacy	0.25	0.50	0.60	0.85	0.90	0.95	0.70	0.70	С	29
Sinfonia Reflecta	0.25	0.15	0.10	0.10	0.15	0.15	0.10	0.15	Е	29
Sinfonia Silencia	0.45	0.90	1.00	1.00	1.00	1.00	1.00	1.00	А	29
Sinfonia Silencia   Humancare	0.45	0.90	1.00	1.00	1.00	1.00	1.00	1.00	А	29
Sinfonia sports	0.45	0.65	0.80	0.95	1.00	1.00	0.85	0.85	В	29
Trapeze	0.50	0.75	0.80	0.80	0.90	0.90	0.85	0.85	В	30
•										
Wall absorber										
Corpus	0.70	0.95	0.95	1.00	1.00	1.00	1.00	1.00	A	31
Creaprint	0.30	0.70	0.85	0.90	0.90	0.85	0.85	0.90	A	31
Curve	0.30	0.70	0.85	0.90	0.90	0.85	0.85	0.90	A	31
FreeStyle R/Q (40 mm)	0.30	0.70	0.85	0.90	0.90	0.85	0.85	0.90	A	31
FreeStyle TR/TL/QS (20/40 mm)	0.30	0.65	0.80	0.80	0.80	0.80	0.80	0.80	В	31
Selecta	0.30	0.03	0.85	0.90	0.90	0.85	0.85	0.90	A	31
S 60	0.30	0.40	0.70	0.85	0.90	1.00	0.83	0.70	C	31
0.00	0.10	0.40	0.70	0.00	0.80	1.00	0.70	0.70	C	31

Equivalent sound absorption area A [m²]


				•			
	125	250	500	1000	2000	4000	Seite
Baffles							
FreeStyle S	0.10	0.20	0.30	0.40	0.40	0.50	31
FreeStyle M	0.20	0.40	0.60	0.80	0.90	0.90	31
FreeStyle L	0.30	0.60	0.90	1.20	1.30	1.40	31
Canopies							
Cloud 150	0.10	0.30	1.20	2.00	2.60	2.60	33
Cloud 200	0.20	0.50	1.60	2.50	2.90	2.90	33
Corpus S1	0.20	0.50	0.60	0.80	0.80	0.80	33
Corpus S2	0.60	0.60	0.80	1.10	1.10	1.10	33
Corpus M1	0.40	0.90	1.20	1.50	1.50	1.60	33
Corpus M2	1.00	1.20	1.40	1.90	2.00	2.10	33
Corpus L1	0.70	1.60	2.10	2.60	2.60	2.60	33
Corpus L2	1.40	2.10	2.50	3.20	3.30	3.30	33
Corpus XL1	0.80	2.20	2.80	3.70	3.70	3.80	34
Corpus XL2	1.30	2.80	3.40	4.40	4.60	4.60	34
Corpus XXL1	1.10	2.90	3.60	4.70	4.80	5.00	34
Corpus XXL2	2.00	3.50	4.30	5.50	5.90	6.00	34
Curve 1	0.50	1.10	1.70	2.30	2.40	2.20	34
Curve 2	0.40	0.80	1.10	1.70	1.70	1.70	34
Selecta one	0.80	1.30	1.90	2.70	2.70	2.70	34
Selecta plus	1.30	2.00	2.80	3.70	3.70	3.60	34
Selecta grande	1.40	2.40	3.40	4.80	4.80	4.60	34
Selecta grande XL	1.90	3.00	4.30	6.00	6.00	5.80	34
Selecta loop Ø 800	0.20	0.40	0.80	1.20	1.20	1.20	35
Selecta loop Ø 1000	0.40	0.80	1.20	1.70	1.70	1.70	35
Selecta loop Ø 1200	0.60	1.10	1.60	2.20	2.20	2.20	35
Selecta Metall one	0.40	1.00	1.20	1.10	1.10	1.10	35
Selecta Metall plus	0.60	1.50	1.80	1.60	1.60	1.60	35
Selecta Metall grande	0.90	2.00	2.40	2.20	2.20	2.20	35
Square	0.30	0.50	1.40	2.00	2.30	2.30	35

# Bamboo | Constellation




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.40
250	0.50
500	0.60
1000	0.70
2000	0.75
4000	0.70
NRC	0.65
$\alpha_{w}$	0.70
SRA	0.70

# Bamboo | Regular perforated




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.25
250	0.40
500	0.55
1000	0.75
2000	0.60
4000	0.40
NRC	0.60
$\alpha_{w}$	0.55
SRA	0.55

# Bolero




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.50
250	0.75
500	0.80
1000	0.80
2000	0.90
4000	0.90
NRC	0.85
$\alpha_{w}$	0.85
SRA	0.85

# Brillianto A (14 mm)




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.45
250	0.80
500	0.85
1000	0.90
2000	0.95
4000	1.00
NRC	0.90
$\alpha_{w}$	0.90
SRA	0.95

# Brillianto A (20 mm)




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.50
250	0.80
500	0.90
1000	0.90
2000	1.00
4000	1.00
NRC	0.95
$\alpha_{w}$	0.95
SRA	0.95

## Constellation




Freq. [Hz]	Suspension depth E200
	$\alpha_{\mathbf{p}}$
125	0.30
250	0.50
500	0.60
1000	0.75
2000	0.85
4000	0.80
NRC	0.70
$\alpha_{w}$	0.70
SRA	0.75

## Cosmos/N




Freq. [Hz]	Suspension depth E200
E3	$\alpha_{\mathbf{p}}$
125	0.35
250	0.55
500	0.65
1000	0.70
2000	0.65
4000	0.50
NRC	0.65
$\alpha_{w}$	0.65
SRA	0.60

# Flexo




Freq.	Suspension depth E200
	$\alpha_{\mathbf{p}}$
125	0.50
250	0.80
500	0.85
1000	0.90
2000	1.00
4000	0.95
NRC	0.90
$\alpha_{w}$	0.90
SRA	0.90

### **Humancare Lab**




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.40
250	0.55
500	0.60
1000	0.75
2000	0.90
4000	0.95
NRC	0.70
$\alpha_{w}$	0.70
SRA	0.80

## **Humancare Plus**




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.40
250	0.70
500	0.80
1000	0.90
2000	1.00
4000	1.00
NRC	0.90
$\alpha_{w}$	0.90
SRA	0.95

# Humancare Pro




Freq. [Hz]	Suspension depth E200 $\alpha_{ m p}$
125	0.40
250	0.85
500	0.95
1000	0.90
2000	1.00
4000	1.00
NRC	0.95
$\alpha_{w}$	0.95
SRA	0.95

### Janus | Constellation




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.30
250	0.45
500	0.65
1000	0.90
2000	0.90
4000	0.75
NRC	0.70
$\alpha_{w}$	0.70
SRA	0.80

# Janus | Cosmos/N




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.25
250	0.40
500	0.70
1000	0.85
2000	0.65
4000	0.50
NRC	0.65
$\alpha_{w}$	0.65
SRA	0.70

## NEW Sandila/N




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.50
250	0.60
500	0.70
1000	0.75
2000	0.60
4000	0.40
NRC	0.65
$\alpha_{w}$	0.60
SRA	0.60

# **NEW Sandila NRC**




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.50
250	0.60
500	0.65
1000	0.85
2000	0.75
4000	0.50
NRC	0.75
$\alpha_{w}$	0.65
SRA	0.70

### Ocean




Freq.	Suspension depth E200
	$\alpha_{\mathbf{p}}$
125	0.50
250	0.80
500	0.90
1000	0.90
2000	1.00
4000	1.00
NRC	0.95
$\alpha_{w}$	0.95
SRA	0.95

# $OWAlux^{\tiny{(\! R \!)}}$




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.15
250	0.15
500	0.10
1000	0.15
2000	0.15
4000	0.10
NRC	0.15
$\alpha_{\mathbf{w}}$	0.15
SRA	0.15

# OWAplan<sup>70</sup>




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.40
250	0.55
500	0.55
1000	0.70
2000	0.90
4000	1.00
NRC	0.70
$\alpha_{w}$	0.65
SRA	0.80

# OWAplan<sup>90</sup>




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.50
250	0.75
500	0.85
1000	0.90
2000	1.00
4000	1.00
NRC	0.90
$\alpha_{\mathbf{w}}$	0.90
SRA	0.95

## Pix




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.50
250	0.80
500	0.85
1000	0.90
2000	1.00
4000	0.95
NRC	0.90
$\alpha_{w}$	0.90
SRA	0.90

### RAW concrete




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.40
250	0.50
500	0.60
1000	0.75
2000	0.85
4000	0.80
NRC	0.70
$\alpha_{w}$	0.70
SRA	0.75

# RAW grey




Freq. [Hz]	Suspension depth E200
	$\alpha_{\mathbf{p}}$
125	0.45
250	0.75
500	0.85
1000	0.90
2000	1.00
4000	1.00
NRC	0.90
$\alpha_{\mathbf{w}}$	0.90
SRA	0.95

# Sanitas® 02 | Plain




Freq. [Hz]	Suspension depth E200
[112]	$\alpha_{\mathbf{p}}$
125	0.15
250	0.15
500	0.10
1000	0.15
2000	0.15
4000	0.10
NRC	0.15
$\alpha_{w}$	0.15
SRA	0.15

## Sinfonia and Sinfonia | Humancare




Freq. [Hz]	Suspension depth E200
	$\alpha_{\mathbf{p}}$
125	0.50
250	0.80
500	0.85
1000	0.90
2000	1.00
4000	0.95
NRC	0.90
$\alpha_{w}$	0.90
SRA	0.90

### Sinfonia Balance




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.45
250	0.50
500	0.80
1000	1.00
2000	1.00
4000	1.00
NRC	0.80
$\alpha_{w}$	0.80
SRA	0.95

# Sinfonia black or grey




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.50
250	0.65
500	0.80
1000	0.85
2000	0.95
4000	1.00
NRC	0.80
$\alpha_{w}$	0.85
SRA	0.90

# Sinfonia c and Sinfonia c | Humancare




Freq. [Hz]	Suspension depth E200 $\alpha_{ m p}$
125	0.40
250	0.60
500	0.65
1000	0.65
2000	0.75
4000	0.75
NRC	0.70
$\alpha_{w}$	0.70
SRA	0.70

### Sinfonia FR




Freq. [Hz]	Suspension depth E200
	$\alpha_{\mathbf{p}}$
125	0.30
250	0.35
500	0.55
1000	0.80
2000	0.90
4000	0.90
NRC	0.65
$\alpha_{w}$	0.60
SRA	0.80

# Sinfonia Privacy




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.25
250	0.50
500	0.60
1000	0.85
2000	0.90
4000	0.95
NRC	0.70
$\alpha_{w}$	0.70
SRA	0.80

### Sinfonia Reflecta




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.25
250	0.15
500	0.10
1000	0.10
2000	0.15
4000	0.15
NRC	0.10
$\alpha_{w}$	0.15
SRA	0.15

# Sinfonia Silencia and Sinfonia Silencia | Humancare




Freq. [Hz]	Suspension depth E200 α <sub>p</sub>
125	0.45
250	0.90
500	1.00
1000	1.00
2000	1.00
4000	1.00
NRC	1.00
$\alpha_{w}$	1.00
SRA	1.00

# Sinfonia sports




Freq. [Hz]	Suspension depth E200 $\alpha_{\rm p}$
125	0.45
250	0.65
500	0.80
1000	0.95
2000	1.00
4000	1.00
NRC	0.85
$\alpha_{w}$	0.85
SRA	0.95

# Trapeze




Freq. [Hz]	Suspension depth E200 $\alpha_p$
125	0.50
250	0.75
500	0.80
1000	0.80
2000	0.90
4000	0.90
NRC	0.85
$\alpha_{w}$	0.85
SRA	0.85

# Corpus




Freq. [Hz]	$lpha_{ m p}$
125	0.70
250	0.95
500	0.95
1000	1.00
2000	1.00
4000	1.00
NRC	1.00
$\alpha_{w}$	1.00
SRA	1.00

# Creaprint, Curve and Selecta




Freq. [Hz]	$lpha_{ ext{p}}$
125	0.30
250	0.70
500	0.85
1000	0.90
2000	0.90
4000	0.85
NRC	0.85
$\alpha_{w}$	0.90
SRA	0.90

# FreeStyle




Freq. [Hz]	FreeStyle TR/TL/QS (20/40 mm) $\alpha_p$	FreeStyle R/Q (40 mm) $\alpha_p$
125	0.30	0.30
250	0.65	0.70
500	0.80	0.85
1000	0.80	0.90
2000	0.80	0.90
4000	0.80	0.85
NRC	0.80	0.85
$\alpha_{\mathbf{w}}$	0.80	0.90
SRA	0.80	0.90

## S 60




Freq. [Hz]	$lpha_{ m p}$
125	0.15
250	0.40
500	0.70
1000	0.85
2000	0.90
4000	1.00
NRC	0.70
$\alpha_{w}$	0.70
SRA	0.85

# FreeStyle




Freq. [Hz]	FreeStyle S A [m <sup>2</sup> ]	FreeStyle M A [m²]	FreeStyle L A [m²]
125	0.10	0.20	0.30
250	0.20	0.40	0.60
500	0.30	0.60	0.90
1000	0.40	0.80	1.20
2000	0.40	0.90	1.30
4000	0.50	0.90	1.40

## Cloud




Cloud 150 A [m <sup>2</sup> ]	Cloud 200 A [m <sup>2</sup> ]
0.10	0.20
0.30	0.50
1.20	1.60
2.00	2.50
2.60	2.90
2.60	2.90
	A [m²]  0.10  0.30  1.20  2.00  2.60

# Corpus S




Freq. [Hz]	Corpus S1 A [m <sup>2</sup> ]	Corpus S2 A [m <sup>2</sup> ]
125	0.20	0.60
250	0.50	0.60
500	0.60	0.80
1000	0.80	1.10
2000	0.80	1.10
4000	0.80	1.10

# Corpus M




Freq. [Hz]	Corpus M1 A [m <sup>2</sup> ]	Corpus M2 A [m <sup>2</sup> ]
125	0.40	1.00
250	0.90	1.20
500	1.20	1.40
1000	1.50	1.90
2000	1.50	2.00
4000	1.60	2.10

# Corpus L




Corpus L1 A [m <sup>2</sup> ]	Corpus L2 A [m <sup>2</sup> ]
0.70	1.40
1.60	2.10
2.10	2.50
2.60	3.20
2.60	3.30
2.60	3.30
	0.70 1.60 2.10 2.60 2.60

# Corpus XL




Freq. [Hz]	Corpus XL1 A [m²]	Corpus XL2 A [m <sup>2</sup> ]
125	0.80	1.30
250	2.20	2.80
500	2.80	3.40
1000	3.70	4.40
2000	3.70	4.60
4000	3.80	4.60

# Corpus XXL




Freq. [Hz]	Corpus XXL1 A [m <sup>2</sup> ]	Corpus XXL2 A [m²]
125	1.10	2.00
250	2.90	3.50
500	3.60	4.30
1000	4.70	5.50
2000	4.80	5.90
4000	5.00	6.00

### Curve 1 and Curve 2




Freq. [Hz]	Curve 1 A [m²]	Curve 2 A [m²]
125	0.50	0.40
250	1.10	0.80
500	1.70	1.10
1000	2.30	1.70
2000	2.40	1.70
4000	2.20	1.70

# Selecta one, plus, grande and grande XL




Freq. [Hz]	Selecta one A [m²]	Selecta plus A [m²]	Selecta grande A [m²]	Selecta grande XL A [m²]
125	0.80	1.30	1.40	1.90
250	1.30	2.00	2.40	3.00
500	1.90	2.80	3.40	4.30
1000	2.70	3.70	4.80	6.00
2000	2.70	3.70	4.80	6.00
4000	2.70	3.60	4.60	5.80

# Selecta loop




Freq. [Hz]	Ø 800 mm A [m²]	Ø 1000 mm A [m²]	Ø 1200 mm A [m²]
125	0.20	0.40	0.60
250	0.40	0.80	1.10
500	0.80	1.20	1.60
1000	1.20	1.70	2.20
2000	1.20	1.70	2.20
4000	1.20	1.70	2.20

# Selecta Metall one, plus and grande



Freq. [Hz]	Selecta one A [m²]	Selecta plus A [m²]	Selecta grande A [m <sup>2</sup> ]
125	0.40	0.60	0.90
250	1.00	1.50	2.00
500	1.20	1.80	2.40
1000	1.10	1.60	2.20
2000	1.10	1.60	2.20
4000	1.10	1.60	2.20

# Square



Freq. [Hz]	Square A [m²]
125	0.30
250	0.50
500	1.40
1000	2.00
2000	2.30
4000	2.30

# Sound protection

This brochure provides an overview regarding sound protection and about the sound absorption performance of OWAcoustic mineral tiles. If you would like more information or have any other question on acoustics our OWAconsult specialists would be happy to help.

#### **Thomas Höllein**

tel +49 9373 201-161

#### **OWAconsult**

tel +49 9373 201-222 info@owaconsult.de www.owaconsult.de



The information in this brochure is up-to-date at the time of publication. Subject to alterations. Please contact our competence team OWAconsult for specific advice. Our experts will be happy to answer your questions under the following contact details: tel: +49 9373 201-444 or e-mail: info@owaconsult.de